

Geotechnical

✓ Soil relations:

- Void ratio: $e = \frac{V_v}{V_s}$
- Water content: $w = \frac{W_w}{W_s}$
- Buoyant unit weight: $\gamma' = \gamma_{\text{sat}} - \gamma_w$
- Porosity: $n = \frac{V_v}{V_t}$
- Saturation: $S = \frac{V_w}{V_v}$

✓ Stress in soil:

- $\sigma = \gamma z$
- $u = \gamma_w z$
- $\sigma' = \sigma - u$

✓ Compaction, zero air voids: $\gamma_{\text{zav}} = \frac{G_s \gamma_w}{1 + w G_s}$

✓ Consolidation:

- $S_c = \frac{C_c H}{1 + e_0} \log \frac{\sigma'_f}{\sigma'_0}$
- $T_v = \frac{C_v t}{H_d^2}$

✓ Shear strength: $\tau = c + \sigma' \tan \phi$

✓ Bearing capacity:

- $q_{\text{ult}} = c N_c + \gamma D_f N_q + 0.5 \gamma B N_\gamma$
- $q_{\text{allow}} = \frac{q_{\text{ult}}}{FS}$

✓ Earth pressure:

- $K_a = \tan^2(45^\circ - \phi/2)$
- $K_p = \tan^2(45^\circ + \phi/2)$
- $\sigma_h = K \sigma_v$

Hydraulics

✓ Continuity: $Q = VA$

✓ Fluid statics and energy:

- Bernoulli: $\frac{p}{\gamma} + z + \frac{V^2}{2g} = \text{constant}$
- Hydrostatic pressure: $p = \gamma h$
- Force on a submerged surface: $F = \gamma h_c A$

✓ Pipe flow:

- Reynolds number: $Re = \frac{VD}{\nu}$
- Darcy-Weisbach: $h_f = f \frac{L}{D} \frac{V^2}{2g}$

✓ Pump power: $P = \frac{\gamma Q h_p}{\eta}$

✓ Open channels:

- Manning (SI): $V = \frac{1}{n} R^{2/3} S^{1/2}$; US units use $\frac{1.49}{n}$
- Froude number: $Fr = \frac{V}{\sqrt{gD}}$
- Critical depth (rectangular): $y_c = \left(\frac{q^2}{g} \right)^{1/3}$

Hydrology

✓ Rational method: $Q = CiA$

✓ NRCS (SCS) runoff:

- $Q = \frac{(P - 0.2S)^2}{P + 0.8S}$
- $S = \frac{1000}{CN} - 10$

✓ Time of concentration (Kirpich): $T_c = 0.0078 L^{0.77} S^{-0.385}$